


BOAT LIFT WAREHOUSE

WWW.BOATLIFTWAREHOUSE.COM


Swim Raft



Boat Lift Warehouse ♦ www.boatliftwarehouse.com ♦ 877-GOT-LIFT
2315 Nahunta Rd NW ♦ Pikeville, NC 27863


Read all instructions before doing anything.

1 Parts List



2

Lay out outer frame to be assembled upside down.




3

Slide the outer frame together.


Attention!

Make sure all corners are squared up. If the corners appear to not fit, it is because they are not completely squared up. Adjust the frame until you have a nice fit.





4

Mount the side beam clamps on each corner. Wait until all clamps are in place before tightening.




5

Mount the float supports but do not tighten. Lay a float on the raft to measure out the spacing for the float supports, then tighten the float supports.



6

Mount the floats with washers on both sides and a locknut on the bottom.



7

Warning! Have someone to help flip the raft over. The raft will weigh about 300 lbs at this point, so be careful that you have enough people who can manage this weight.

Add the decking to the top of the raft, and then place it in the water. Make sure to have some way of anchoring the raft or tie it to the shore or dock.

